

What is Contouring?

Contouring is the science of representing the vertical dimension of the terrain on a two dimensional map.

Define Contour

A **Contour is an imaginary outline of the terrain** obtained by joining its points of equal elevation
A contour line is a line drawn on a topographic map **to indicate ground elevation or depression**
Index contours are bold or thicker lines that appear at every fifth contour line.
Supplementary lines
Intermediates





Define Contour Interval (CI)


Contour interval is the ***difference between the levels of consecutive contour lines on a map***
The contour interval is constant in a given map
It is indicated on the contour lines


Define Horizontal Equivalent (HE)

Horizontal equivalent is the **horizontal distance between two consecutive contour lines** measured to the scale of the map.

The distance must be measured on the map and converted to actual distance by multiplying with the scale of the map

The horizontal equivalent varies with slope. Closer distance indicates steep slope and wider distance gentle slope





Factors which govern the selection of contour interval

S.No	Factor	Select High CI like 1m, 2m, 5m or more	Select Low CI like 0.5m, 0.25m, 0.1m or less
1	Nature of ground	If the ground has large variation in levels, i.e. hills and ponds	If the terrain is fairly level
2	Scale of the map	For small scale maps covering a wide area of varying terrain	For large scale maps showing details of a small area
3	Extent of survey	For rough topographical map meant for initial assessment only	For preparation of detailed map for execution of work
4	Time and resources available	If less time and resources are available	If more time and resources are available

Common Values of the Contour -Interval

The common values of the contour interval adopted for various purposes:-

i) For large scale maps of **flat country**, for building sites, for detailed design work and for calculation of quantities of earth work; **0.2 to 0.5 m.**

ii) For **reservoirs and town planning** schemes; **0.5 to 2m.**

iii) For **location surveys**. 2 to 3m.

iv) For **small scale maps of broken country** and general topographic work; **3m,5m,10m,or 25m.**

Gradient

*Gradient represents the **ascending or descending slope of the terrain** between two consecutive contour lines.*

- The slope or gradient is **usually stated in the format 1 in S**, where **1 represents the vertical** component of the slope and **S its corresponding horizontal** component measured in the same unit.
- The gradient between two consecutive contour lines can also be expressed in terms of $\tan\theta$ as follows: $\boldsymbol{tan\,\theta = CI/HE}$*… both measured in the same unit.*

Characteristic of Contours

i) All points on a contour line are of the same elevation.

ii) No two contour lines can meet or cross each other except in the rare case of an overhanging vertical cliff or wall

iii) Closely spaced contour lines indicate steep slope

iv) Widely spaced contour lines indicate gentle slope

v) Equally spaced contour lines indicate uniform slope

vi) Closed contour lines with higher elevation towards the centre indicate hills

vii) Closed contour lines with reducing levels towards the centre indicate pond or other depression.


Viii) Contour lines of ridge show higher elevation within the loop of the contours. Contour lines cross ridge at right angles.


ix) Contour lines of valley show reducing elevation within the loop of the contours. Contour lines cross valley at right angles.

x) All contour lines must close either within the map boundary or outside.

Contours of terrain having different types of slopes


Widely separated contour lines indicate a gentle slope. Contour lines that are very close together indicate a steep slope.






Characteristic of Contours

A series of closed contour lines on the map represent a hill , if the higher values are inside



A HILL

A series of closed contour lines on the map indicate a depression if the higher values are outside




A DEPRESSION


Characteristic of Contours

Contour line **cross ridge or valley line at right angles.**


If the **higher values are outside** the bend, it represents **a Valley**



If the **higher values are inside** the bend, it represents **a Ridge**




Contours deflect uphill at valley lines and downhill at ridge lines. Contour lines in U-shape cross a ridge and in V-shape cross a valley at right angles. The concavity in contour lines is towards higher ground in the case of ridge and towards lower ground in the case of valley



Valley and Ridge lines


Characteristic of Contours

Contour lines never run into one another except in the case of a vertical cliff. In this case ,several contours coincide and the horizontal equivalent becomes zero.




OVERHANGING CLIFF

Contour lines cannot merge or cross one another on map except in the case of an overhanging cliff.



OVERHANGING CLIFF

Contours do not pass through permanent structures such as buildings



Contour Map

A map showing contour lines is known as Contour map.

A contour map gives an idea of the altitudes of the surface features as well as their relative positions in plan serves the purpose of both, a plan and a section.

USES OF CONTOUR MAP

(i) A contour map furnishes information regarding the features of the ground , whether it is flat, undulating or mountainous.

(ii) From a contour map , sections may be easily drawn in any direction

(iii) Intervisibility between two ground points plotted on map can be ascertained


(iv) It enables an engineer to approximately select the most economical or suitable site for an engineering project such as a road, a railway, a canal or a pipe line etc.


(v) A route of a given grade can be traced on the map.

(vi) Catchment area and capacity of a reservoir may be determined from the contour map.

(vii) Contour map may be used to determine the quantities of earth work.

How does a contour map look like?





Different Ground Features on a Contour map

Methods of Contouring

(1) Direct Method and

(2) Indirect Method.

Methods of Contouring: Direct Method

Direct method of contouring can be employed using Level and Staff as follows:

Vertical control:

Staff reading is taken on a Bench Mark

H.I is determined

Staffs are held at points of desired R.L by trail and error method

Horizontal Control:


After having located the points on various contours, they are to be surveyed with the suitable control system for their horizontal location

For small area-Chain svy

For large area- Traverse svy (Theodolite and compass)

Methods of Contouring: Direct Method


- The points are then plotted on paper and points are joined to have desired contour line.
- Vertical and horizontal control may be carried out simultaneously by two parties (large area),or by the same party, one after other (small area)
- This method is most accurate but very slow and tedious as *a lot of time is wasted* in searching points of the same elevation for a contour.
- This is suitable for small area and where great accuracy is required



Methods of Contouring: Direct Method By Radial Lines Lines

This method is suitable for small areas, where a single point in the centre can command the whole area.

Radial lines are laid out from the common centre by theodolite or compass and their positions are fixed up by horizontal angles and bearings.



Indirect Method

There are mainly three method of contouring in indirect method:

(i) By Squares.
(ii) By Cross Section
(iii) By Tacheometric Method

Indirect Method

- In this method the points located and surveyed are not necessarily on the contour lines but the spot levels are taken along the series of lines laid out over the area.
- The spot levels of the several representative points representing hills, depressions, ridge and valley lines and the changes in the slope all over the area to be contoured are also observed.
- Their positions are then plotted on the plan and the contours drawn by interpolation. This method of contouring is also known as contouring by spot levels.


This method is commonly employed in all kinds of surveys as this is cheaper, quicker and less tedious as compared to direct method.


Indirect Method - By Squares

In this method, the whole area is divided into number of squares, the side of which may vary from 5m to 30m depending upon the nature of the ground and the contour interval.

The square need not be of the same size throughout.


The corners of the squares are pegged out and the R.L. of these points are determined with a level.





Indirect Method: By Cross- Sections

- This method is most suitable for the surveys of long narrow strips such as a road, railway or canal etc.
- Cross sections are run transverse to the centre line of the work and representative points are marked along the lines of cross-section.
- The cross-section lines need not necessarily be at right angles to the centre line of the work. This may be inclined at any angle to the centre line if necessary.
- The levels of the points along the section lines are plotted on the plan and the contours are then interpolated as usual as shown in the fig.



Indirect Method: By Tacheometric method

- This method is *most suitable in hilly areas* as the number of stations which can be commanded by a techeometer is far more than those by a level and thus the number of instrument settings are considerably reduced.
- A number of *radial lines* are *laid out* at a *known angular interval* and representative points are marked by pegs along these radial lines.
- Their *elevations and distances* are then *calculated and plotted* on the plan and the *contour lines* are then *interpolated.*

DRAWING THE CONTOUR LINES

- Contour lines are drawn as fine and smooth free hand curved lines. Sometimes they are represented by broken lines .
- They are inked in either in black or brown colour.
- A drawing pen gives a better line than a writing pen and French curves should be used as much as possible .
- Every fifth contour is made *thicker* than the rest.
- The elevation of contours must be written in a uniform manner, either on the higher side or in a gap left in the line .
- When the contour lines are *very long*, their *elevations are written at two* or *three places* along the contour .
- In the case of small scale maps, it is sufficient to figure every *fifth* contour.